


# Advantages and Disadvantages of Using DSP Filtering on Oscilloscope Waveforms

Application Note 1494



<b>Table of Contents</b>	
<b>Introduction</b> . . . . .	<b>1</b>
<b>Waveform-reconstruction filtering</b> . . . . .	<b>3</b>
<b>Magnitude-flattening filtering</b> . . . . .	<b>6</b>
<b>Phase-correction filtering</b> . . . . .	<b>7</b>
<b>Noise-reduction filtering</b> . . . . .	<b>9</b>
<b>Bandwidth-enhancement filtering</b> . . . . .	<b>10</b>
<b>Conclusion</b> . . . . .	<b>12</b>
<b>Glossary</b> . . . . .	<b>13</b>
<b>Support, Services, and Assistance</b> . . . . .	<b>14</b>

## Introduction

All of today's high-speed real-time sampling oscilloscopes use various forms of digital signal processing (DSP) on digitized oscilloscope waveforms. Some engineers are concerned that filtering digitized data with software may alter the true nature of a captured signal. However, the captured waveform is only a representation of the actual input signal, and "raw" digitized data captured by an oscilloscope includes altered/distorted results

contributed by the scope's front-end hardware filtering. In a perfect world, real-time oscilloscopes would have infinitely fast sample rates, perfectly flat frequency responses, linear phase responses, no noise, and infinite bandwidth. But in the real world, oscilloscopes have hardware limitations that produce errors. DSP filtering ultimately can correct for hardware-induced errors to improve measurement accuracy and enhance display quality.

There are five different characteristics of DSP filtering commonly employed in today's higher-performance real-time scopes:

<b>DSP filtering</b>	<b>Corrects for</b>
Waveform reconstruction	Limited sample rate
Magnitude flattening	Non-flat frequency response
Phase correction	Non-linear phase response
Noise reduction	Instrument's noise floor
Bandwidth enhancement	Limited bandwidth

Each of these filter characteristics can be implemented in a single finite-impulse response (FIR) software filter in real-time sampling oscilloscopes. This application note explores the purposes of these different characteristics of DSP filters, and discusses the benefits and possible tradeoffs associated with each one. This application note does not provide information about the actual software implementation of the various DSP filters.

## Waveform-reconstruction filtering

The purpose of waveform reconstruction filtering is to “fill-in” the waveform data record between discrete and evenly sampled real-time acquired data points. Filling-in the data points enhances both the measurement accuracy and the viewability of digitized waveforms on faster timebase ranges. You can use equivalent-time/repetitive sampling to fill in the data, but for real-time applications, repetitive sampling is not an option. The waveform must be captured in a single-shot acquisition. Software waveform reconstruction filtering is the only other possibility.

The simplest type of waveform reconstruction uses a linear-interpolation filter. Although this type of filter will improve measurement resolution, accuracy, and display quality, a more accurate type of interpolation is  $\sin(x)/x$  reconstruction filtering, which is a symmetrical filter. Figure 1 shows an example of a 3-GHz sine wave captured and filtered with linear reconstruction (top/blue trace) and  $\sin(x)/x$  reconstruction (bottom/yellow trace). With linear reconstruction, we can clearly see the discretely spaced 50-ps sample points generated by this 20-GSa/s oscilloscope.

$\sin(x)/x$  filtering will almost always provide a more accurate representation of the input signal with a few caveats. First of all, for  $\sin(x)/x$  reconstruction filtering to be absolutely accurate, the digitized input signal must not possess any frequency components beyond the Nyquist frequency ( $f_N$ ). The Nyquist frequency is defined

to be  $1/2$  of the sample frequency ( $f_S$ ). For a scope that can sample at 20 GSa/s, the Nyquist frequency is 10 GHz. To provide maximum bandwidth while guaranteeing that no frequency components beyond 10 GHz are ever sampled, the oscilloscope theoretically must have a hardware brickwall filter at 10 GHz or lower.

Unfortunately, brickwall filters are not physically realizable in hardware. The red trace in Figure 2 represents the characteristics of a brickwall filter; all frequency components below the Nyquist frequency are perfectly passed, and all frequency components above the Nyquist frequency are perfectly eliminated.




Figure 1. Linear vs  $\sin(x)/x$  reconstruction




Figure 2. Various hardware filter responses

## Waveform-reconstruction filtering (continued)

In the past, lower-bandwidth scopes typically have had Gaussian-type roll-off characteristics, as represented by the green trace (bottom) in Figure 2. If you are digitizing very fast signals using this slow roll-off characteristic, there often will be significant components of the signal above the  $-3\text{dB}$  bandwidth point. Frequency components beyond the Nyquist frequency (represented by the hashed area in this graph) will be aliased. If a digitized signal is grossly aliased where the fundamental input frequency is beyond the Nyquist frequency, the displayed waveform will appear to be untriggered when you are viewing repetitive real-time acquisitions, and measurements of digitized points may be in error by orders of magnitude. When the input signal's fundamental input frequency is below the Nyquist frequency, but harmonics of the signal are beyond the Nyquist frequency, you may observe a waveform on the oscilloscope's display with edges that "wobble." For this reason, Agilent Technologies traditionally has limited the bandwidth of lower-bandwidth real-time scopes that have Gaussian roll-off characteristics to  $1/4$  the sample rate, which is  $1/2$  the Nyquist frequency. This significantly limits the captured energy of signals with harmonic-frequency content beyond the Nyquist frequency.

For some of the newer higher-bandwidth, real-time scopes with bandwidths from 2 GHz to 6 GHz, the hardware roll-off characteristic begins to approach a theoretical brickwall filter. In most oscilloscope measurement cases, this is a desirable characteristic. This type of hardware filter, called a high-order maximally flat filter, is illustrated by the blue trace (middle) in Figure 2. With this type of hardware filter, most of the in-band frequencies are passed with minimal attenuation, and most of the out-of-band frequencies are significantly attenuated. With a high-order maximally flat response, the scope's bandwidth can then begin to approach the Nyquist limit. Agilent recommends that for scopes with a high-order maximally flat response, the bandwidth of the scope should be limited to no more than 0.4 times the sample rate. In other words, for waveform reconstruction using  $\sin(x)/x$  filtering to be effective and accurate, the bandwidth of a scope that samples at 20 GSa/s should not exceed 8 GHz.

What are the tradeoffs in employing a  $\sin(x)/x$  software reconstruction filter in an oscilloscope? If the input signal is initially band-limited, or if the hardware of the oscilloscope properly limits the sampled frequency components beyond

the Nyquist frequency, the tradeoffs are minimal. But if the input signal has significant high-frequency components beyond the system bandwidth, one artifact of  $\sin(x)/x$  filtering is the possibility of software-created pre-shoot and over-shoot of the reconstructed waveform. This effect is essentially Gibbs phenomena. The software-created over-shoot is often hidden by inherent over-shoot in the actual input signal, as well as over-shoot created by the scope's hardware filtering. Because pre-shoot is usually not actually present in the signal, oscilloscope users often question the validity of  $\sin(x)/x$  filtering. But software-induced errors such as pre-shoot can pale in comparison to uncorrected hardware-induced errors when you are measuring out-of-band signals.

Remember, measuring an out-of-band signal simply means that you are attempting to capture a signal which has frequency components beyond the specified bandwidth capability of the oscilloscope. This means that measured results can include significant components of error due to hardware limitations. For example, if you attempt to measure an input signal with an edge speed of 20 ps (10% to 90%), a 6-GHz oscilloscope will produce measured edge speeds in the range of 70 ps, which is a

## Waveform-reconstruction filtering (continued)

250 percent error. Although pre-shoot and over-shoot produced by software filtering may be intuitively disturbing, these phenomena are minor sources of error compared to hardware-induced over-shoot and edge-speed errors, which are often overlooked.

To reduce software-induced pre-shoot, oscilloscope designers could employ  $\sin(x)/x$  reconstruction filtering *without* phase correction to the acquired out-of-band waveform. (See page 7 for more information on phase-correction filtering.) Although the resultant filtered waveform that exhibits lots of over-shoot with minimal pre-shoot may feel more comfortable, accuracy of amplitude and edge-speed measurements will be degraded. Proper DSP filtering *with* linear phase correction will produce the most accurate measurements on fast rising and falling edges.

The best approach is to try to ignore the pre-shoot artifact and take this unintuitive “wobble” at the beginning of fast-edge pulses as a sign that the real-time oscilloscope is employing a DSP filter that most accurately represents the overall characteristics of the out-of-band input signal. You also can take the pre-shoot artifact as a sign that you are pushing the real-time oscilloscope beyond its intended

bandwidth measurement capabilities. You may want to consider using a higher-bandwidth sampling oscilloscope, such as Agilent’s 86100C, for your measurement application. If repetitive sampling is not a possibility, then you may need to just accept the real-time measurement results as the best that is possible with today’s real-time sampling and filtering technology.

As previously mentioned,  $\sin(x)/x$  DSP filtering will significantly improve measurement resolution and accuracy to well beyond the real-time sample interval ( $1/\text{sample-rate}$ ). With Agilent’s 20-GSa/s 54855A oscilloscope, delta-time measurement accuracy can be improved to less than  $\pm 1$  ps with the use of  $\sin(x)/x$  filtering on single-shot acquisitions. In some cases there are also throughput tradeoffs when you use  $\sin(x)/x$  filtering. In other words, the filter causes your scope display to update more slowly. However, the enhanced accuracy advantages of using  $\sin(x)/x$  filtering typically far outweigh all disadvantages.

All major real-time scope vendors today allow you to decide if you want to use  $\sin(x)/x$  filtering. This mode of operation is a default selection in Agilent oscilloscopes, but you can override this selection if you choose.

## Magnitude-flattening filtering

The purpose of magnitude-flattening filtering is to correct for a non-flat frequency response of the hardware characteristics of the oscilloscope. Ideally, oscilloscopes would have a perfectly flat hardware response all the way out to the natural bandwidth roll-off characteristics of the oscilloscope, as shown by the traces in Figure 2. This means that if you measure a sine wave with constant amplitude, but vary the frequency, you would always measure the same amplitude until reaching the upper roll-off frequencies. Unfortunately, as you approach the bandwidth limit of a scope, flatness-of-response tends to degrade. Often, there can be a combination of hardware-induced attenuation and peaking at particular frequencies. In fact, oscilloscope design engineers will often intentionally induce peaking in the scope's hardware response near the bandwidth limit in order to compensate for minor frequency-dependent attenuation and to push the scope's frequency response to a higher bandwidth.

The red trace (top) in Figure 3 shows the typical hardware/analog frequency response of Agilent's 54855A real-time 6-GHz oscilloscope. As you can see, the hardware response of this scope meets the  $-3$  dB hardware bandwidth criteria of 6 GHz, but the response also shows about  $+1$  dB of peaking at approximately 3.5 GHz, and nearly  $+2$  dB of peaking at approximately 5.5 GHz. Oscilloscope manufacturers today do not specify the flatness of their scope's frequency response. The only point in the frequency domain scope makers specify is the  $-3$  dB bandwidth point. Even if a scope had  $+6$  dB of peaking, which would translate into 60 percent amplitude error at a particular in-band frequency, as long as the  $-3$  dB point is higher than the specified bandwidth, the scope is considered to be within specification. But just as attenuation at higher frequencies can degrade the accuracy of measurements, so can amplification/peaking degrade measurement accuracy.

The blue trace (bottom) in Figure 3 shows the corrected magnitude frequency response of the 54855A using magnitude-flattening filtering. With this DSP/software filter, the corrected frequency response of the oscilloscope typically does not deviate more than  $\pm 0.5$  dB until the response naturally rolls off near the specified 6 GHz bandwidth. This particular characteristic of the scope's FIR filter is not user-selectable – it always runs when you are sampling at the scope's maximum sample rate to correct for always-present hardware filtering errors. The combination of the software and hardware filter produces more accurate data than data produced by the hardware filter alone.




Figure 3. Magnitude-flattening filter response

## Phase-correction filtering

High-speed digital signals are composed of multiple frequency components including the fundamental and harmonics. Ideally, the fundamental and harmonics of a digital signal should all be in-phase and have no delay between the various frequency components, as shown in Figure 4. Unfortunately, the oscilloscope's hardware adds unwanted phase shift to the higher-order components of high-speed signals that can only be eliminated by either significantly increasing the instrument's bandwidth, or by correcting with phase-correction DSP filtering. Figure 5 shows an example where the 5th harmonic (green trace) is delayed from both the fundamental and 3rd harmonic. The result will be a distorted digital waveform on the oscilloscope's display. Without phase correction, this distortion usually manifests as excessive over-shoot in the digitized waveform, along with reduced edge speeds. High-speed digital designers often overlook the over-shoot component of distortion, thinking that the measured over-shoot is actually present on the input signal. But it may not be, and may actually be an artifact of the inadequacy of the hardware to "keep-up" at all input frequencies.




Figure 4. In-phase harmonics




Figure 5. 5th harmonic delayed

## Phase-correction filtering (continued)

The red trace in Figure 6 shows the typical frequency-dependent phase error induced by the 54855A hardware at higher input frequencies. The blue trace in this graph shows the corrected phase response using phase-correction DSP/software filtering. As you can see, this software filter corrects for all phase errors to well beyond the bandwidth specification of the instrument.

Figure 7 shows a simulation of a digitized fast-edge signal, with and without phase-correction, for a 6-GHz hardware system based on a high-order maximally flat response. The one artifact that you will note in the phase-corrected waveform (left/red trace) is the presence of minimal pre-shoot and over-shoot on the waveform. Again, neither the pre-shoot nor the over-shoot are actually present in the simulated input signal, which had an infinitely fast rise time, but are artifacts of the linear-phase system response and signal content beyond the  $-3$  dB frequency. But don't overlook the excessive over-shoot on the non-phase corrected waveform (right/blue trace). With phase-correction, the overall perturbation errors on both the top and base of this waveform have been improved. Most importantly though, timing measurements such as the rise times and fall times are much more accurate when phase correction is applied on either in-band or out-of-band signals. Again, phase-correction filtering is not user-selectable in Agilent's 54855A oscilloscope; it is always running to correct for added hardware phase errors.




Figure 6. Correct and uncorrected phase response




Figure 7. Pulse response with and without phase correction

## Noise-reduction filtering

As you would expect, noise-reduction filtering reduces the effect of the oscilloscope's noise floor. Oscilloscopes are broadband instruments and the higher the bandwidth the higher the noise floor will be. This hardware-induced error component is unavoidable in broadband instruments. With Agilent's 54855A oscilloscope, you can selectively use noise-reduction filtering to improve measurement accuracy, but there is a big tradeoff. When the scope's FIR filter includes noise-reduction filtering characteristics, the bandwidth of the instrument is reduced.

Figure 8 shows an example of capturing a 1-GHz sine wave using the 6-GHz bandwidth 54855A oscilloscope without the use of noise-reduction filtering. Using the infinite-persistence display mode, after 1000 accumulated acquisitions we see a band of noise on this captured sine wave that is induced by the oscilloscope's hardware noise

floor. At this setting, the instrument-induced noise measured approximately 2.8 mV RMS. The upper/yellow trace shows the input signal scaled to near full-scale at 100 mV/div. The lower/green trace shows a 10X waveform expansion of this waveform near its peak.

Figure 9 shows the same 1-GHz sine wave, but now captured using 2-GHz bandwidth noise-reduction filtering. After 1000 accumulated acquisitions, we see a much cleaner waveform due to a nearly 2:1 reduction in the system's noise floor. Again, the upper/yellow trace shows the input signal scaled at 100 mV/div and the lower/green trace shows an expansion of the waveform near its peak allowing us to see more clearly the effects of the scope's reduced noise floor using noise-reduction filtering.

When testing lower-bandwidth signals, or signals with relatively

slow edge speeds, engaging noise-reduction filtering will often enhance accuracy of both amplitude and timing measurements. One example involves measuring jitter. One of the largest, but often overlooked, components of error in jitter measurements is jitter/timing-error contributed by vertical noise. There is a direct relationship between vertical noise and timing error as a function of the slew rate of the signal. Although it may be counter-intuitive, reducing the bandwidth of your measurement system may actually improve the accuracy of jitter measurements when you are measuring in-band signals. Turning on noise-reduction filtering will automatically reduce instrument-induced jitter due to an excessive instrument noise floor. Because of the obvious trade-offs (bandwidth versus noise), use of noise-reduction filtering is user-selectable in Agilent's 54855A oscilloscope.




Figure 8. Default 6-GHz bandwidth mode with 2.8 mV RMS scope noise floor




Figure 9. 2-GHz noise-reduction mode with 1.6 mV RMS scope noise floor

## Bandwidth-enhancement filtering

Bandwidth-enhancement filtering, sometimes referred to as “bandwidth boosting,” is probably the least intuitive type of DSP filtering. It is employed today in some high-bandwidth real-time oscilloscopes. How can you enhance the bandwidth of a system once the hardware has attenuated the signal? The simple answer is, pump it back up with software. Once you break a digitized signal down into its various sine wave frequency components, you can use software to selectively “amplify” the various frequency components that are attenuated based on software filtering characteristics that are a mirror image (up to the boosted  $-3$  dB point) of the hardware roll-off characteristic of the scope, as shown in Figure 10. The red trace (bottom) in this graph shows a typical hardware frequency response. The green

trace (top) represents the bandwidth-enhancement filter, and the blue trace (middle) represents the improved bandwidth response of the system, which you can see has been “boosted” to a higher frequency. In addition to increasing the bandwidth, this particular filter also generates a sharper roll-off characteristic for the oscilloscope to help reduce high-frequency noise and to help eliminate aliasing when testing out-of-band input signals.

Again, there is one big tradeoff. As we mentioned, an oscilloscope is a broadband instrument, and the noise floor of the instrument can significantly degrade measurement results. With bandwidth-enhancement filtering, the noise floor of the instrument also is selectively amplified. So, there is a signal-to-noise

tradeoff when you use these bandwidth-enhancing characteristics of the scope’s FIR DSP filter.

Although bandwidth enhancement filtering may be a fairly new capability in some of today’s higher-bandwidth real-time oscilloscopes, this is not a new technique in the test-and-measurement industry. Agilent has been using bandwidth-enhancement techniques for years in network analyzers and spectrum analyzers. In fact, Agilent first used this technique in an oscilloscope to simulate faster edge speeds when performing TDR measurements with a 20-GHz sampling oscilloscope. This technique is known as “normalization” in today’s sampling oscilloscopes with TDR measurement capability.




Figure 10. Bandwidth-enhancement filtering

## Bandwidth-enhancement filtering (continued)

Figure 11 shows an example of measuring an out-of-band signal using a 6-GHz oscilloscope. The input signal has an approximate risetime of 50 ps (based on a 10% to 90% measurement criteria). But since the basic hardware of the oscilloscope has a risetime specification of 70 ps, we measure a risetime of just 74 ps. With the use of 7-GHz bandwidth-enhancement filtering, we can now make a more accurate measurement on this signal of approximately 66 ps, as shown in Figure 12. However, you can see that the baseline noise on both the top and base of this waveform has

increased. In the standard 6-GHz bandwidth mode, the noise floor of the scope measures approximately 3 mV RMS at the 100 mV/div setting. The noise floor increases to approximately 6 mV RMS when using 7-GHz bandwidth-enhancement filtering.

Another benefit of DSP filtering with bandwidth-enhancement on Agilent's 54855A oscilloscopes is high-impedance active probing measurements can be performed up to 7-GHz system bandwidth. No longer is the differential active probe the weakest link in the oscilloscope measurement chain.



Figure 11. Risetime measurement without bandwidth-enhancement




Figure 12. Risetime measurement with 7-GHz bandwidth-enhancement

## Conclusion

Many engineers today tend to trust hardware filtering, but are skeptical of DSP filtering because it is based on software. As we illustrated in this application note, DSP filtering on oscilloscope waveforms is employed for the purpose of correcting hardware filtering errors. Instead of thinking of software filtering as a form of data manipulation, it is more appropriate to think of it as data un-manipulation. Software has been used for years to correct for hardware errors in oscilloscopes, including gain/offset calibration and de-skewing delay between channels. It makes sense to use software also to correct for more complex frequency-dependent sources of hardware errors using DSP filtering.

Some of the filter characteristics discussed in this application note have minimal or no disadvantages, such as magnitude-flattening and phase-correction filtering. For these reasons, these particular filter characteristics are not user-selectable but run as a default operation when the

Agilent 54855A oscilloscope is sampling at the maximum specified sample rate (20 GSa/s). Because we believe that  $\sin(x)/x$  waveform-reconstruction filtering also improves measurement accuracy and display quality, the characteristics of this particular filter runs as a default operating mode of the oscilloscope, but you can easily disabled it. The tradeoffs using  $\sin(x)/x$  filtering are primarily associated with throughput, not accuracy.

Other characteristics of the scope's FIR DSP filter, including noise-reduction and bandwidth-enhancement filtering have very definite tradeoffs in terms of bandwidth and noise. For this reason, neither of these filter characteristics run as a default mode of operation of the oscilloscope; you must turn them on to use them.

As long as you are aware of the tradeoffs inherent in some filtering types, it makes sense to use DSP filtering to improve the accuracy and resolution of today's real-time oscilloscopes.

## Related Literature

Publication Title	Publication Type	Publication Number
<i>Infiniium 54850 Series Oscilloscope, InfiniMax 1130</i>	Data sheet	5988-7976EN/ENUS
<i>Understanding Oscilloscope Frequency Response and its Effect on Rise Time Accuracy</i>	Application Note 1420	5988-8008EN
<i>Time-Domain Response of Agilent InfiniMax Probes and 54850 Series Infiniium Oscilloscope</i>	Application Note 1461	5988-9608EN
<i>Improving TDR/TDT Measurements Using Normalization</i>	Application Note 1304-5	5988-2490EN
<i>Agilent Technologies Option 008 Enhanced Bandwidth Software for the 54855A Infiniium Oscilloscope</i>	Data sheet	5989-1066EN

## Product Web site

For copies of this literature, contact your Agilent representative or visit our product Web site at:  
[www.agilent.com/find/infiniimax](http://www.agilent.com/find/infiniimax)

## Glossary

**DSP** digital signal processing

**Brickwall filter** a theoretical but unrealizable filter that perfectly passes all frequency components of the signal below a particular cut-off frequency, and rejects all frequency components of the signal above the cut-off frequency

**Equivalent-time sampling** digitizing an input signal repetitively using multiple acquisition cycles

**Finite-impulse response (FIR) filter** a software filter whose output is a weighted sum of the input data

**Gaussian filter** a filter that exhibits relatively slow roll-off characteristics

**Gibbs phenomena** symmetrical filter-induced pre-shoot and over-shoot due to truncation of Fourier series beyond a given frequency

**High-order maximally flat filter** a filter that approaches the sharp roll-off characteristics of a brickwall filter

**In-band** frequency components of signals that are less than the specified bandwidth frequency

**Infinite persistence** a display mode in oscilloscopes that accumulates multiple acquisitions on the scope's display to show worst-case deviations

**Jitter** any time deviation (error) from the ideal instance in time when a signal edge/transition should occur

**Nyquist frequency ( $f_N$ )** which is the frequency that is equal to  $1/2$  the sampling frequency ( $f_S$ )

**Out-of-band** frequency components of signals that are greater than the specified bandwidth frequency

**Real-time sampling** digitizing an input signal from a single-shot acquisition using a high rate of sampling

**Sin(x)/x filtering** characteristics of software filtering that reconstructs a sampled waveform to provide higher data resolution that will more accurately represent the original un-sampled input signal when Nyquist's rules are observed

### Agilent Technologies' Test and Measurement Support, Services, and Assistance

Agilent Technologies aims to maximize the value you receive, while minimizing your risk and problems. We strive to ensure that you get the test and measurement capabilities you paid for and obtain the support you need. Our extensive support resources and services can help you choose the right Agilent products for your applications and apply them successfully. Every instrument and system we sell has a global warranty. Support is available for at least five years beyond the production life of the product. Two concepts underlie Agilent's overall support policy: "Our Promise" and "Your Advantage."

#### Our Promise

Our Promise means your Agilent test and measurement equipment will meet its advertised performance and functionality. When you are choosing new equipment, we will help you with product information, including realistic performance specifications and practical recommendations from experienced test engineers. When you use Agilent equipment, we can verify that it works properly, help with product operation, and provide basic measurement assistance for the use of specified capabilities, at no extra cost upon request. Many self-help tools are available.

#### Your Advantage

Your Advantage means that Agilent offers a wide range of additional expert test and measurement services, which you can purchase according to your unique technical and business needs. Solve problems efficiently and gain a competitive edge by contracting with us for calibration, extra-cost upgrades, out-of-warranty repairs, and on-site education and training, as well as design, system integration, project management, and other professional engineering services. Experienced Agilent engineers and technicians worldwide can help you maximize your productivity, optimize the return on investment of your Agilent instruments and systems, and obtain dependable measurement accuracy for the life of those products.



### Agilent Email Updates

[www.agilent.com/find/emailupdates](http://www.agilent.com/find/emailupdates)

Get the latest information on the products and applications you select.



### Agilent Direct

[www.agilent.com/find/agilentdirect](http://www.agilent.com/find/agilentdirect)

Quickly choose and use your test equipment solutions with confidence.

### Agilent T&M Software and Connectivity

Agilent's Test and Measurement software and connectivity products, solutions and developer network allows you to take time out of connecting your instruments to your computer with tools based on PC standards, so you can focus on your tasks, not on your connections. Visit [www.agilent.com/find/connectivity](http://www.agilent.com/find/connectivity) for more information.

By internet, phone, or fax, get assistance with all your test & measurement needs

#### Online assistance:

[www.agilent.com/find/assist](http://www.agilent.com/find/assist)

#### Phone or Fax

##### United States:

(tel) 800 829 4444

##### Canada:

(tel) 877 894 4414

(fax) 905 282 6495

##### China:

(tel) 800 810 0189

(fax) 800 820 2816

##### Europe:

(tel) (31 20) 547 2323

(fax) (31 20) 547 2390

##### Japan:

(tel) (81) 426 56 7832

(fax) (81) 426 56 7840

##### Korea:

(tel) (82 2) 2004 5004

(fax) (82 2) 2004 5115

##### Latin America:

(tel) (305) 269 7500

(fax) (305) 269 7599

##### Taiwan:

(tel) 0800 047 866

(fax) 0800 286 331

##### Other Asia Pacific Countries:

(tel) (65) 6375 8100

(fax) (65) 6836 0252

Email: [tm\\_asia@agilent.com](mailto:tm_asia@agilent.com)

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2004

Printed in USA May 24, 2004

5989-1145EN

