

# **Agilent U1818A/B Active Differential Probe**

## **Handling Guides and Tips**



**Agilent Technologies**

# Notices

© Agilent Technologies, Inc. 2009

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

## Manual Part Number

U1818-90002

## Edition

First Edition, November 2009

Printed in Malaysia

Agilent Technologies, Inc.  
Phase 3 Bayan Lepas Free Industrial Zone  
Bayan Lepas, Penang 11900 Malaysia

## Certification

Agilent Technologies certified that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (NIST, formerly NBS), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

## Warranty

**The material contained in this document is provided "as is," and is subject to being changed, without notice, in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.**

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## Restricted Rights Legend

U.S. Government Restricted Rights. Software and technical data rights granted to the federal government include only those rights customarily provided to end user customers. Agilent provides this customary commercial license in Software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data - Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

## Safety Notices

### CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

---

### WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

---

# Contacting Agilent

For more information, please contact your nearest Agilent office.

## Americas

Canada	(877) 894-4414
Latin America	305 269 7500
United States	(800) 829-4444

## Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	81 426 56 7832
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Thailand	1 800 226 008

## Europe

Austria	0820 87 44 11
Belgium	32 (0) 2 404 93 40
Denmark	45 70 13 15 15
Finland	358 (0) 10 855 2100
France	0825 010 700
Germany	01805 24 6333
Ireland	1890 924 204
Italy	39 02 92 60 8484
Netherlands	31 (0) 20 547 2111
Spain	34 (91) 631 3300
Sweden	0200-88 22 55
Switzerland (French)	41 (21) 8113811 (Opt 2)
Switzerland (German)	0800 80 53 53 (Opt 1)
United Kingdom	44 (0) 118 9276201
Other European Countries:	<a href="http://www.agilent.com/find/contactus">www.agilent.com/find/contactus</a>


Or, go to [www.agilent.com/find/assist](http://www.agilent.com/find/assist) for more information.



# Contents

<b>1</b>	<b>Handling Guide</b>	<b>7</b>
	Connecting/Disconnecting Probe Heads	8
	Handling the Probe Cable	10
	Handling the Probe Amplifier	11
	Handling the Differential Browsers with Ergonomic Handle	12
	Handling SMA Probe Heads	13
	Temperature Rating	14
	Securing Probe Heads and Amplifiers to Your DUTs	15
<b>2</b>	<b>Maintenance and Service Instructions</b>	<b>17</b>
	Maintenance	18
	Service Instructions	18





# 1

## Handling Guide

Handling Guide 8

"Connecting/Disconnecting Probe Heads" on page 8

"Handling the Probe Cable" on page 10

"Handling the Probe Amplifier" on page 11

"Handling the Differential Browsers with Ergonomic Handle" on page 12

"Handling SMA Probe Heads" on page 13

"Temperature Rating" on page 14

"Securing Probe Heads and Amplifiers to Your DUTs" on page 15

This section will assist you in properly handling your U1818A/B Active Differential probes to maximize their lifetime of operation and maintain their high performance.




# Handling Guide

This probe has been designed to withstand a moderate amount of physical and electrical stress. However, with an active probe, the technologies necessary to achieve high performance, do not allow the probe to be unbreakable. You should treat the probe with care. It can be damaged if excessive force is applied to the probe tip. This damage is considered to be abuse and will void the warranty when verified by Agilent Technologies service professionals.

This section will assist you in properly handling your Active Differential probes to maximize their lifetime of operation and maintain their high performance.

## Connecting/Disconnecting Probe Heads

When disconnecting a probe head from an amplifier, pull the probe head connectors straight out of the socket as shown in [Figure 1-1](#). When removing or disconnecting a probe head, hold the amplifier by grasping the indentations located on the sides of the amplifier (as shown in [Figure 1-1](#)). There are also indentations on many of the probe head sockets so you have a convenient place to grasp there as well. When connecting a probe head to an amplifier, push straight in also.




**Figure 1-1** Pull the probe head straight out to disconnect it from the amplifier.

Never bend the probe head in order to “pop” it loose from the amplifier. Also, do not wiggle the probe head up and down or twist it to remove the connectors from the sockets. This can damage the pins in the amplifier or the probe head itself. [Figure 1-2](#) is an example of an improper way to disconnect the probe head.



**Figure 1-2** An improper way to disconnect a probe head from an amplifier

To see if the pins in the probe amplifier are bent, visually inspect them by looking in the sockets on the amplifier. Notice in [Figure 1-3](#) that the pins are straight (as they should be).



**Figure 1-3** Straight pins in an amplifier

If you connect and disconnect probe heads using the appropriate method, these pins should not bend. Always remember to apply enough force to pull the probe head straight out or push it straight in. Do not wiggle, twist, or bend it in any way.

## Handling the Probe Cable

In general, you need to be careful not to kink the cable, twist it, or bend it too much.


For example, slamming a drawer or dropping a heavy item on a cable can kink it and significantly degrade the probe's performance.

Also, when a probe is attached to instrument, you need to be careful not to let a chair or other object crash into the face of the instrument because it will hit the probe cable where it exists the probe amplifier and bend it well beyond its limit.

When storing the probe, it is best to coil the cable in a large radius and avoid a net twist in the cable during the process. This can be done in a similar manner to how garden hoses or extension cords are typically coiled.

You can start by wrapping the cable around your thumb (Figure 1-4 - first picture). Then continue to circle your thumb, but provide a slight twist with each rotation. This will allow the cable rotations to lie flat against each other and will eliminate the net twisting of the cable in the end.

Note that the radius of the coil must be fairly large so it does not induce kinking or bending.



**Figure 1-4** The recommended way to coil and store your probe

## Handling the Probe Amplifier


The probe amplifier contains a delicate circuit board. You, therefore, need to treat it carefully and take standard precautions (for example, not dropping it repeatedly or from large heights, not getting it wet, not smashing it with heavy objects, etc.).

### **CAUTION**


These probes are sensitive ESD devices so standard precautions need to be used to not ruin the probe from the build-up of static charges.

## Handling the Differential Browsers with Ergonomic Handle

Because of their small size, it can be difficult to hold the differential browsers for extended periods of time. The ergonomic handle can be used to more comfortably hold the browser. [Figure 1-5](#) shows how to mount the browser in the ergonomic handle and [Figure 1-6](#) shows how to remove the browser from the ergonomic handle.




**Figure 1-5** Steps to mount the browser in the ergonomic handle



**Figure 1-6** Steps to remove the browser from the ergonomic handle

## Handling SMA Probe Heads

The U1818A/B probe amplifier can become damaged when used with the N5380A or E2695A SMA probe heads. Use the Agilent N5380-64701 SMA Head Support to prevent damage. Make sure to plug the probe amplifier into the SMA head before installing the SMA Head Support and do not attempt to plug or unplug the SMA head from the probe amplifier while it is in the SMA Head Support housing. [Figure 1-7](#) shows how to attach the SMA Head Support using two provided screws.



**Figure 1-7** Attaching the SMA Head Support


## Temperature Rating

U1818A/B probe amplifier have a specified operating temperature range of 0°C to +50°C. However, the probe heads can be operated over a much larger range of temperatures. If you need to make measurements at temperatures outside the range of the amplifier, the N5450A Extreme Temperatures Cable Extension Kit is your solution.

These cables can be used to physically separate the amplifier from the probe head to allow you to operate the probe head inside a temperature chamber while the probe amplifier remains outside the chamber.

## Securing Probe Heads and Amplifiers to Your DUTs

When soldering a probe to a circuit, you should first provide some strain relief by using low temperature hot glue (use as little as possible) or non-conductive double-sided tape. Do not use super glue and do not get the low temperature hot glue on the actual probe head tip as this can damage the precision components of your probing system (only use the low temperature hot glue on the probe head cables). The provided velcro pads can be used to secure your probe amplifier casing to the board.



**Figure 1-8** Correct securing methods



**Figure 1-9** Incorrect securing method because glue is placed on the probe head tip

