

# Keysight M8085A MIPI Receiver Test Solutions Plug-in

Calibration, Conformance and  
Characterization Procedures

Installation Guide

# Notices

## Copyright Notice

© Keysight Technologies 2016

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Keysight Technologies, Inc. as governed by United States and international copyright laws.

## Manual Part Number

M8085A-91040

## Edition

Edition 1.0, April 2016

## Published by:

Keysight Technologies  
Deutschland GmbH,  
Herrenberger Str. 130,  
71034 Böblingen, Germany

## Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

## U.S. Government Rights

The Software is “commercial computer software,” as defined by Federal Acquisition Regulation (“FAR”) 2.101. Pursuant to FAR 12.212 and 27.405-3 and Department of Defense FAR Supplement (“DFARS”) 227.7202, the U.S. government acquires commercial computer software under the same terms by which the software is customarily provided to the public. Accordingly, Keysight provides the Software to U.S. government customers under its standard commercial license, which is embodied in its End User License Agreement (EULA), a copy of which can be found at <http://www.keysight.com/find/sweula>. The license set forth in the EULA represents the exclusive authority by which the U.S. government may use, modify, distribute, or disclose the Software. The EULA and the license set forth therein, does not require or permit, among other things, that Keysight: (1) Furnish technical information related to commercial computer software or commercial computer software documentation that is not customarily provided to the public; or (2) Relinquish to, or otherwise provide, the government rights in excess of these rights customarily provided to the public to use, modify, reproduce, release, perform, display, or disclose commercial computer software or commercial computer software documentation. No additional government requirements beyond those set forth in the EULA shall apply, except to the extent that those terms, rights, or licenses are explicitly required from all providers of commercial computer software pursuant to the FAR and the DFARS and are set forth specifically in writing elsewhere in the EULA. Keysight shall be under no obligation to update, revise or otherwise modify the Software. With respect to any technical data as defined by FAR 2.101, pursuant to FAR 12.211 and 27.404.2 and DFARS 227.7102, the U.S. government acquires no greater than Limited Rights as defined in FAR 27.401 or DFARS 227.7103-5 (c), as applicable in any technical data.

## Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED “AS IS,” AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, KEYSIGHT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED, WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. KEYSIGHT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR OF ANY INFORMATION CONTAINED HEREIN. SHOULD KEYSIGHT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT SHALL CONTROL.

## Safety Information

### CAUTION

A CAUTION notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION notice until the indicated conditions are fully understood and met.

### WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

## Contents

1	Installation Procedure	
1.1	Prerequisites	5
1.2	License Requirements	6
1.3	Installation Steps	6
1.4	How to Access the MIPI Receiver Test Solutions Plugins through M8070A System Software	10
1.5	Contacting Keysight Technologies	11



# 1 Installation Procedure

- 1.1 Prerequisites / 5
- 1.2 License Requirements / 6
- 1.3 Installation Steps / 6
- 1.4 How to Access the MIPI Receiver Test Solutions Plugins through M8070A System Software / 10
- 1.5 Contacting Keysight Technologies / 11

This document describes the installation procedure for Keysight M8085A MIPI Receiver Test Solutions Plugin. After the successful installation, you will be able to access the following plugins:

- MIPI D-PHY Editor - Allows the user to set the DUT and test configuration.
- MIPI D-PHY CTS - Support the MIPI D-PHY signal generator configurations for single and multi-lane testing with the ValiFrame Test Automation Software.

## 1.1 Prerequisites

The following are the pre-requisites for installing MIPI Receiver Test Solutions plugin:

- The MIPI Receiver Test Solutions plugin has to be installed separately along with the M8070A system software. Please make sure that the system should already have M8070A software (version 3.1.12.1 or above) installed on it.
- MIPI Receiver Test Solutions plugin installer which is either available on CD or can be downloaded from Keysight webpage: [www.keysight.com](http://www.keysight.com)
- MIPI Receiver Test Solutions plugin license: ("M8085A-DTA | M8085A-DNA | M8085A-DDA")

## 1.2 License Requirements

The MIPI Receiver Test Solutions plugin is a licensed feature. To enable it, the **M8085A-DTA | M8085A-DNA | M8085A-DDA** licenses are required.

## 1.3 Installation Steps

Follow the given steps to install MIPI Receiver Test Solutions plugin on your system.

1. Double-click the executable. This executable file will be available either on CD or Web.



The following window will appear as shown in [Figure 1](#).




Figure 1: MIPI Plugin Setup Wizard

2. Click on the **Next** button to continue to the next step. The license agreement of the MIPI Plugin setup appears as shown in [Figure 2](#).




Figure 2: MIPI Plugin Setup License Agreement Window

3. Read all the terms and conditions of the license agreement carefully and select "I accept the terms of the License Agreement" option. Then, click on **Next** to continue. After pressing the **Next** button, the following window appears as shown in [Figure 3](#).




Figure 3: MIPI Plugin Setup Choose Components Window

4. Click on the **Next** button to continue to the next step. The following window will appear as shown in [Figure 4](#).




Figure 4: MIPI Plugin Setup Choose Install Location Window

5. Click the **Browse...** button to select the destination folder where the software shall be installed.
6. Next, click the **Install** button to install the software. The following window will appear as shown in [Figure 5](#).






Figure 5: MIPI Plugin Setup Installation Status Window

7. Once the installation is completed, click the **Next** button to continue. The following window will appear as shown in [Figure 6](#).




Figure 6: N5990A Installation Completion Window

8. Click on the **Finish** button to complete the MIPI Receiver Test Solutions plugin installation.

## 1.4 How to Access the MIPI Receiver Test Solutions Plugins through M8070A System Software

Follow the steps to access an installed plug-in through M8070A system software:

1. Launch M8070A system software user interface.
2. In the M8070A user interface, go to **Menu Bar** and then click **Application menu**. It will show “MIPI D-PHY Editor” and “MIPI D-PHY CTS” plug-ins.
3. Select the **MIPI D-PHY Editor** plug-in. The **MIPI D-PHY Editor** plug-in user interface will appear as shown in [Figure 7](#).




Figure 7: D-PHY Editor Plug-in User Interface

- Similarly, you can select the **MIPI D-PHY CTS** plug-in. The **MIPI D-PHY CTS** plug-in user interface will appear as shown in **Figure 8**.




Figure 8: D-PHY CTS Plug-in User Interface

For complete details on how to operate the **MIPI D-PHY Editor plugin** user interface, refer to the *MIPI D-PHY Editor User Guide*.

For complete details on how to operate the **MIPI D-PHY CTS plugin** user interface, refer to the *MIPI D-PHY Receiver Test Configuration User Guide*.

## 1.5 Contacting Keysight Technologies

For more information on Keysight Technologies' products, applications or services, please contact your local Keysight office. The complete list is available at: [www.keysight.com/find/contactus](http://www.keysight.com/find/contactus).



This information is subject to change without notice.  
© Keysight Technologies 2016  
Edition 1.0, April 2016



M8085A-91040

[www.keysight.com](http://www.keysight.com)